







COMPE

Scales		Po
1	: 10000	x1
1	: 200	
1	: 1500	
1	: 500	
1	: 2500	
1	: 400	
1	: 1000	
1	: 500	✓

1:10560 set 149.2 x 1.116

Serial # 8

Scales	Position of the vernier on the tracer bar	Value of the vernier unit on the measuring roller	
1" = 50'	1 5 4 . 8	40" (1:1)	0.016"
1" = 25'	" " "	10"	" " "
1" = 20'	1 4 3 . 9	6"	0.015"
1" = 100'	" " "	150"	" " "
1" = 40'	1 1 6 . 9	20"	0.0125"
1" = 20'	" " "	5"	" " "
1" = 30'	1 0 2 . 0	10"	0.0111"
1" = 60'	" " "	40"	" " "
1" = 100'	9 0 . 0	100"	0.01"
1 : 1	1 4 9 . 2	0.1 Sq cm	

2 3 1 3 2
" " "
2 3 4 1 8
" " "
2 4 4 8 6
" " "
— — —
— — —
— — —
2 3 0 7 9

COMPENSATION PLANIMETER

No. 8 / 8

Scales	Position of the vernier on the tracer bar	Value of the vernier unit on the measuring roller		Constant
1 : 10000	x100 = ha	10 m ²	(1:1) 10 mm ²	
1 : 200	1 4 9 . 2	0.4 m ²	"	2 3 0 7 9
1 : 1500	1 3 0 . 6	20 m ²	8.8 mm ²	2 3 5 7 9
1 : 500	1 1 6 . 0	2 m ²	8 mm ²	2 4 2 8 8
1 : 2500	→ x5 = ha	0.5 m ²	"	
1 : 400	8 6 . 8	1 m ²	6.25 mm ²	—
1 : 1000	6 5 . 8	5 m ²	5 mm ²	—
1 : 500 ✓	4 8 . 6	1 m ²	4 mm ²	—

2 3 4 1 8
" " "
2 4 4 8 6
" " "